



**Figure 1: Pin connections for the X5101 and X5104 modules.**

**X5101 Pin Connections:**

Pin	Signal
1	P+28V
2	P+28V
3	PGND
4	PGND

**X5104 Pin Connections:**

Pin	Signal
1	A+10V
2	A+5V
3	AGND
4	A-10V
5	PHGND
6	H-R
7	H-L
8	H-DET

		XS105
D+5V	D+5V	1
DGND	DGND	2
D+3V3	D+3V3	3
AGND	AGND	4
A+5V	A+5V	5

		XS102
DGND	DGND	1
FL+	FL+	2
FL-	FL-	3
-21V	-21V	4
CPU5V	CPU5V	5
STBY	STBY	6

		XS103
H-R	H-R	1
PHGND	PHGND	2
H-L	H-L	3
H-DET	H-DET	4