

For example, if the password of mobile phone is set to be 1122, input 1122.

* The default password is '1122', please change the password to your own as quick as possible. Suppose that you forgot your phone password, you must contact with your retailer or local authorized maintenance center to unlock your password.

Keypad Lock:

- Set the wait time of Keypad Lock. After setup, the keypad will be automatically locked when the handset is not used within the designated time.
- **Lock the Keypad in standby status:** press Left Soft Key firstly and then press # key.
- **Unlock the Keypad in standby status:** press Left Soft Key firstly and then press # key; or press any key according screen prompt to do it.

Change password:

can change the phone password.

Restore Factory

Set the functions of your phone to default settings: 1122

Sound effects

Sound special effects: open the balance, can set the sound effects style.

Dynamic application

Open the function can switch wallpaper, MP3, in standby status.

5.11 File Management

Insert memo card, in the menu, you can create new folder to manage your data, store different files, such as music, picture etc. enter file management interface, separately list the total capacity and capacity of memory available, enter option interface can see the options below:

open: confirm the item, show the file list of memory.

Create new file folder: confirm the item, can rename the folder created.

Rename: change the file folder name.

Delete: delete the file folder selected.

Sorting: can sort by name, type, time and size.

Function parameters as below:

Function	illustration	Optional	path
Ring file	MID/WAV /AMR	default	Audio folder
MP3 file	MP3	default	My Music folder
Picture file	BMP/GIF/JPG	Default	Photos folder
Video file	3GP/MP4	Default	Video folder
Electronic book	TXT	default	Ebook folder


5.12 Email

Please see the email function introduction in message.

5.13 Wireless LAN

The setting of Wi-Fi decide whether the phone linked to the Internet by the local Wi-Fi network.

Open or close Wi-Fi: select Wi-Fi, then open or close Wi-Fi

Add Wi-Fi network: select "Wi-Fi", after a while, the phone check the network within the communication, then choose one. If necessary, please input password, then gentle press "add" (the network needs password has  icon)


Once you manual add a Wi-Fi network, when within communication, you phone will auto join it. If find many network in use, then the phone will join the network last time.

When the phone joined to Wi-Fi, the Wi-Fi icon on the status bar on the top of screen will show the strength of signal, the more the bar, the stronger the signal.

Set the phone ask if you want join new network: select Wi-Fi then find open or close "ask for join network"

When you try to visit Internet, and you not in the Wi-Fi range used before, this time the option will point the phone to find other network.

The phone will display all Wi-Fi network list that can be used, you can choose one in it. If "ask if join network" closed, and when the last used network or cell mobile network isn't can be used, you must manual to join in another network to link to Internet.

If you want to forget a network, so the phone will not join it: select Wi-Fi, then gently click the  at the side of the network you have joined before, and gently click "forget the network"

5.14 Ucweb

WAP browser of JAVA, through Wi-Fi to use Ucweb browser.

5.15 Opera mini

WAP browser of JAVA, through Wi-Fi to use Opera mini browser.

5.16 Calculator

Input the numbers to be calculated with numbers 0-9 and input