

5.2.1.1 Call Record

In the menu is the SIM card 1 call records and SIM card 2 call records. The operation is the same, detail as below:

Missed Calls

Enter missed call menu, press confirm to view missed call list.

In call record list interface, you can press confirm to view the detail of record, include date, dial time, number, times.

In detail message interface, you can press option to operate the current selected call record, operation as below:

- ✓ **Delete:** delete the record.
- ✓ **Save:** save the number into SIM card or Handset.
- ✓ **Dial:** dial the phone number.
- ✓ **Edit:** edit the phone number and store it into Phonebook.
- ✓ **send SMS:** send a SMS to current number.
- ✓ **Send MMS:** send a MMS to current number.

Dialed Calls

Enter dialed call menu, press confirm to view dialed call list.

In call record list interface, you can press confirm to view the detail of record, include number, times.

In detail message interface, you can press option to operate the current selected call record, operation as below:

- ✓ **Delete:** delete the record.
- ✓ **Save:** save the number into SIM card or handset.
- ✓ **Dial:** dial the phone number.
- ✓ **Edit:** edit the phone number and store it into Phonebook.
- ✓ **send SMS:** send a SMS to current number.
- ✓ **Send MMS:** send a MMS to current number.

Received Calls

Enter received call menu, press confirm to view received call list.

In call record list interface, you can press confirm to view the detail of record, include date, dialed time, number, times.

In detail message interface, you can press option to operate the current selected call record, operation as below:

- ✓ **Delete:** delete the record.
- ✓ **Save:** save the number into SIM card or handset.
- ✓ **Dial:** dial the phone number.
- ✓ **Edit:** edit the phone number and store it into Phonebook.
- ✓ **send SMS:** send a SMS to current number.
- ✓ **Send MMS:** send a MMS to current number.

Delete records

Enter delete record submenu, you can delete a call record or clear all records.

Call Time

In call time interface, there are four submenu:

- ✓ **Previous call time:** view the time value of the last call.
- ✓ **Total Dialed Calls:** view the total time value of the call out.
- ✓ **Total Received Calls:** view the total time value of Received calls.
- ✓ **All Time Return-to-Zero:** Clear up the data in timing stat and restart time.

Call Cost

Call Cost can store the accumulated charge of call for you.

- ✓ **Previous Call Cost:** View the last call cost.
- ✓ **All Call Cost:** View all the accumulated call cost.
- ✓ **Call Cost Return-to-Zero:** Enter PIN2 code and clear the counter and restart to count the cost.
- ✓ **Cost Limit:** Enter the sub-menu **Cost Limit**, which can be browsed, modified or cancelled. Where, it is essential to enter PIN2 code if you want to modify and cancel.
- ✓ **Price and rate:** Enter the sub-menu price and rate, which can be browsed, modified or cancelled. Where, it is essential to enter PIN2 code if you want to modify and cancel.

Note: You need enter PIN2 code for operating some functions, and please contact your network supplier to receive the password.

* Note: needs network support.

SMS Counter

- ✓ **Sent:** record the sent SMS number.
- ✓ **Received:** record the received SMS number.

You can select the left soft key "reset" to empty the two items respectively.

GPRS Counter

- ✓ **Last Sent:** record the last sent size
- ✓ **Received:** record the last received size.
- ✓ **All transmit:** record all transmit size.
- ✓ **All received:** record all received byte.
- ✓ **Clear counter:** recount

5.2.1.2 Call Setup

Setup

- ✓ **The phone number:** the system default value is used for whether to send the number. Press up/down navigation key to select system default, hide number or send number.
- ✓ **Call Waiting:** open or close Call Waiting. Choose Inquiry