

Car Audio CMU-400

# Service Service


# Service Manual

#### SET BLOCK DIAGRAM







#### MAIN BOARD - CIRCUIT DIAGRAMUNIT





### MAIN BOARD - PCB LAYOUT TOP VIEW





### MAIN BOARD - PCB LAYOUT BOTTOM VIEW














# KEY BOARD - LAYOUT DIAGRAM TOP VIEW




# KEY BOARD - LAYOUT DIAGRAM BOTTOM VIEW






# PB - LAYOUT DIAGRAM TOP VIEW



# PB - LAYOUT DIAGRAM BOTTOM VIEW



# **EXPLORED VIEW - MAIN UNIT**

