



	FE8H1	FE8H2
Ta0C08000	L	L
Ta0C08000a	L	R1
Ra0C08000	L	L
Ra0C08000a	L	L
Ra0PC08000	L	L




J-TAG 32 PINS


JTAG_BD




D_Class_AMP




FM RADIO




MEMORY



BLUE TOOTH




MELODY IC






IMAGE_DSP

DC/DC Down Converter(1.8Volt)




LDO




VDD_0V	0.00V
VDD_1V8	1.80V
VDD_1V2	1.20V
VDD_0V9	0.90V
VDD_0V6	0.60V
VDD_0V3	0.30V
VDD_0V18	0.18V
VDD_0V15	0.15V
VDD_0V1	0.10V
VDD_0V05	0.05V
VDD_0V01	0.01V
VDD_PUMP	1.80V

VDD_0V18	1.80V
VDD_1V8	1.80V
VDD_1V2	1.20V
VDD_0V9	0.90V
VDD_0V6	0.60V
VDD_0V3	0.30V
VDD_0V18	0.18V
VDD_0V15	0.15V

VDD_0V18	1.80V
VDD_1V8	1.80V
VDD_1V2	1.20V
VDD_0V9	0.90V
VDD_0V6	0.60V
VDD_0V3	0.30V
VDD_0V18	0.18V
VDD_0V15	0.15V





THERMISTOR




USB Interface





PCB_HOLE



BATTERY CHARGING






Title		
IF Connector & Charging Schematic		
Size	Document Number	Rev
A3	SAMSUNG/SGH-X700B.B1F & CHARGING	Rev 1.1
Date:	2005.10.26.	Sheet 5 of 7




EARPIECE

MOTOR








KEY BACKLIGHT




CAMERA



CAMERA_KEY



LCD BACKLIGHT



LCD CONNECTOR

