













**A1 ШАССИ ЦВЕТНОГО ТЕЛЕВИЗОРА TV2KR PAL/SECAM, BG//DK, MONO**



**A3 МОДУЛЬ ВИДЕОУСИЛИТЕЛЕЙ КИНСКОПА**



PART	CRT TUBE	
	A36EM75X31	A36AKJ13X20
TT1	OFF	OFF
TT2	ON	ON
TT3	ON	OFF
TT4	OFF	OFF
TT6	OFF	OFF
TT12	ON	OFF
TT13	OFF	ON
TT14	ON	OFF
L502	105 uH	39 uH
CRT1	GZS10-2-104B	GZS8-6-5