

**Set:** can set play background and output to the handset loudspeaker.

**Record:** can record the radio message.

**Files list:** enter Audio file folder.

## 5.10 Setup

This menu include every personal settings.

### Mode setting

Double cards open, only SIM card 1 open, only SIM card 2 open, flight mode.

### Phone Setting

**Time and date setup:** set date and time

- **Time Zone setup:** set time zone of a city.

- **Time /Date Setup:** set the current time and date.

- **Time format Setup:** set the display format of time and date.

**Timing on-off:** set time and open or close the handset within the set time.

**Language:** set the display language of handset menu.

**Preset input method:** choose a default input method.

**Color lamp setting:** set color lamp open / close.

**Preset coding:** provide two code for choose.

**Standby menu display:**

- **Wallpaper:** choose standby interface wallpaper.

- **Screen protection:** choose a screen protecting picture for the main screen in standby interface and set the wait time.

- **Animation for opening:** choose the animation picture for opening.

- **Animation for closing:** choose the animation picture for closing.

- **Display Time and Date:** open or close the current display time in standby interface.

**Greetings:** In standby interface Open or Close greetings. Greetings Content can be edited.

**Designate function key:** designate the quick enter menu via press direction keys in the standby interface.

**Auto update time:** open or close auto update time.

**UART setting:** choose the SIM card 1 or 2 serial port.

**Other Setup:** set the brightness and the delay time of LCD background light.

**Note:** some function needs network supplier support.

### Network Setup

**Network Selection:**

**Auto select:** auto search the network of the SIM card.

**Manual :** search all available networks, manual login.

**Preferential Network:** Pre-save several networks you like.

### Safety Setup

**Safety setup of the SIM card :**

#### v The SIM card 1 Lock :

You can set safety options of your handset in the menu in order to prevent your handset or SIM card from being illegally used.

PIN code can be used to prevent your SIM card from being illegally used. If the current PIN code has been closed, choose Open and start PIN code protection, and your PIN code will be inquired before your handset starts next; if the current PIN code has been opened, choose Close and close PIN code protection, and choose Change PIN code and set new PIN code; please input the old PIN code, new PIN code and repeat the new PIN code in order in accordance with the reminder.

\* Note: if PIN code is input continuously incorrectly to three times, the SIM card will be locked, when, you need PUK code to unlock SIM card. PIN code and PUK code can be offered to you with SIM card, if not, please contact your network supplier. The default PIN code is generally 1234, and please change it to your own set password as soon as possible.

#### - Fixed Dial-up:

When the function operates, the phone numbers in Fixed Dial-up table or of beginning with some certain digits can only be dialed. (Require SIM card support)

- **Mode:** open or close Fixed Dial-up function (input PIN2 code) .

- **Fixed Dialing List:** input the phone number of Fixed Dial-up.

\* Note: to open and close Fixed Dial-up function, it is necessary to input your PIN2 code. Please contact your network supplier to obtain PIN2 code. Open Fixed Dial-up and then enter the calling card which displays the numbers of Fixed Dial-up.

- **Restrict dialing:** restrict dialing out.

- **Change Password:** Change Password, including modifying PIN1 and PIN2 and phone password.

\* Note: part of functions is supported by your network supplier.

**Safety setup of the SIM card 2:** the setup operation consult the safety of the SIM card 1.

#### Phone Lock:

In order to prevent illegal usage, you can set password in your mobile phone. Once this function is chose, each time you power on your phone, you must input phone password, and you can unlock the phone only by this way, and then send or answer the call. Users can remove phone password, in this case, the phone can not prevent illegal usage.

- Input the mobile phone password, use the right soft key to clear error input, and press confirm to finish it.